



Tec Vanlife Rear Door Ladder & Tire Carrier for 2015+ Ford Transit Vans Installation Guide



Note: Please read these instructions thoroughly before beginning the installation.

Tools Required:

- Drill
- Rust-proofing solution
- Wrench/spanner

Package Contents:

- Transit Tire ladder carrier
- Hardware (nuts and washers)

Installation Steps:

Step 1: Position the tire ladder carrier on the driver-side rear door.

Step 2: Mark the hole locations on the rear door hinge where you will need to drill.



Step 3: Drill holes on the rear door hinges using the marked locations. Be sure to apply rust-proofing solution to the drilled holes to prevent corrosion.

Step 4: Enlarge the four holes on the mounting brackets of the tire ladder carrier so that the included M10 bolts can fit through.

Step 5: Bolt the tire ladder carrier to the rear door hinges. Do not tighten the bolts at this stage.



Step 6: Refer to the provided picture to mark the holes that need to be drilled through the rear door, then drill the holes.



Step 7: Apply rust-proofing solution to the newly drilled holes on the rear door.

Step 8: Bolt the tire ladder carrier through the rear door using the hardware and rubber washers included in the package. Please note the rubber washer should stay between the tire ladder carrier and the rear door as the cushion.

Step 9: Tighten the bolts and nuts on the door hinges and the mounting brackets until secure. Ensure that the tire ladder carrier is properly aligned and not overtightened.





Step 10: Your installation is now complete.



Important Notes:

- Check and ensure the tire ladder carrier is level and aligned properly before final tightening.
- Regularly inspect and maintain the carrier to prevent rust and ensure a secure fit.
- Seek professional assistance if you are unsure about any part of the installation process.