


Crossbar_Mounting_Locations SCALE 1:2

NOTE: CROSSBARS FOR TRANSIT MODELS CAN ONLY BE MOUNTED ON UPPER SLOT



UNLESS OTHERWISE SPECIFIED: ALL DIMENSIONS ARE IN INCHES BAR STOCK SURFACE ROUGHNESS IS ACCEPTABLE TOLERANCES: $.XX = \pm .01$ FRACTIONS = ±1/16 ANGLES = 1° $.XXX = \pm .005$ MATERIAL: WEIGHT (LBS): CREATED BY: THIS DRAWING CONTAINS PROPRIETARY AND CONFIDENTIAL INFORMATION OF ALUMINESS PRODUCTS, INC. AND SHALL NOT BE USED, DISCLOSED OR REPRODUCED, IN WHOLE OR IN PART, FOR ANY PURPOSE OTHER THAN TO EVALUATE THIS DRAWING, WITHOUT THE PRIOR WRITTEN CONSENT OF ALUMINESS. ALL INFORMATION CONTAINED HEREIN REMAINS AT ALL TIMES WITHIN ALUMINESS. CREATED DATE: CHECKED BY: XXX CHECKED DATE: XXX XXX DRAWN BY: DRAWN DATE: XXX



HIGH ROOF, EB, CRUISER RACK

| SIZE | PART 1 | NUMBER: | | REV |
|------------|--------|--------------|--|-----|
| A | | 210677 | | |
| SCALE: 1:2 | | SHEET 1 OF 2 | | |

